

Fontana™ Exterior Shower

INSTALLATION INSTRUCTIONS

Part#: 97022 & 97023

PARTS/TOOLS NEEDED:

						
Exterior Shower	Black Rubber Washers	Mounting Screws	Electric Jigsaw (not provided)	Power Drill (not provided)	Teflon Tape (not provided)	Exterior Caulk (not provided)

INSTALLATION INSTRUCTIONS:

- Choose a location that is flat and has a minimum of 10" of rear clearance for hose and water connections.
- Using the dotted line on this sheet as a template, cut the opening for the main body of the shower.
- Apply Teflon tape to center water valve. Use black rubber washers (included) to screw female sprayer hose connection to male collar.
- Insert the shower and mark the four #8 flat head screw holes on the mounting surface.
- Caulk the mounting flange with suitable weather resistant, flexible sealant material.
- Mount shower to opening and drive in screws (included) until secure.
- Connect the faucet set to the on-board water system.

SPECIFICATIONS:

- Designed for use in a pressure regulated, portable water system with a maximum operating pressure of 40 PSI.
- Maximum flow rate with the faucets fully opened - 2.5GPM.
- DO NOT ALLOW TO FREEZE.
- Do not connect directly to a high pressure residential water supply.



97022-A-5
Latching Shower



97023-A-5
Locking Shower



3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
Rev A · 06/17/19