INSTALLATION INSTRUCTIONS

Oblong Courtesy Light

Part#: 69365

PARTS NEEDED:			
	Salar Sa		
Courtesy Light	Mounting Screws	Power Drill (not provided)	Wire Nuts (not provided)

Safety Instructions

- · Disconnect power before installing, adding or changing any component.
- · To avoid a hazard to children, account for all parts and destroy all packing materials.
- · LEDs are polarity sensitive and will not light if not attached properly
- · Operating Voltage: 10 14V DC
- 1. Drill hole in mounting surface for wires
 - Mark screw holes on light onto surface and pre-drill if necessary
 - Attach wires to the power source. Red is positive and black is neutral
 - Screw light to mounting surface until secure



