
## **INSTALLATION INSTRUCTIONS**

## Push Lens Courtesy Light

Part#: 69503-KK




## IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- \*Disconnect power before installing, adding or changing any component.
- \*To avoid a hazard to children, account for all parts and destroy all packing materials.
- \* It is recommended that fuse protection be added to the positive(+) input.
- **1.** Determine the installation location and drill a 3/4" hole. Smooth the hole.



**3.** Using the wiring diagrams below, wire the light to the incoming 12V DC power. Test the light.



**4.** Feed the wires back through the hole and push the light into the mounting surface.





