





Blinker Module

INSTALLATION INSTRUCTIONS

Part#: RNLL1202 & TPB1202

PARTS NEEDED:

			
Blinker Light	Mounting Channel (Purchased separately)	Butt Splice Connectors (Not Provided)	Alcohol Wipes (Not provided)


General Considerations

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not install any luminaire assembly closer than 6" from any combustible materials.
- Max voltage: 12V DC \pm 20%


1. Install the mounting channel into the vehicles light assembly by removing the paper backing and pressing into place. The notched channel may need to be used in order to properly install it along any curves in the light assembly.

The installation location should be cleaned with alcohol wipes (not provided) to ensure proper adhesion of the channel. For more detailed instructions on surface prep please refer to the 3M™ website*.


*http://www.3m.com/3M/en_US/bonding-and-assembly-us/resources/full-story/?storyid=b3996cbd-9954-455f-8e72-88e452ca38c0



2. To install the light into the channel, start at the wire lead end and work the light into the channel going 6" at a time. The light should go into the channel pretty easily by just thumbing it in. Do not use any roller as that may cause damage to the LED circuit.



3. Using the wiring diagram at the right, wire the light to the units power.



3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
Rev A · 10/06/23