

Mod Leg System

Part#: BAL

INSTALLATION INSTRUCTIONS

PARTS/TOOLS NEEDED:

				
Wall Base & Shim	Vertical & Horizontal Legs	Table Base	Screws (not provided)	Power Drill (not provided)

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- It is recommended that fuse protection be added to the positive (+) input.

1. Find a solid, secure wall to mount your MOD Leg system. Place the wall base and shim (if using), using screws (not provided) appropriate for mounting substrate.



2. Slide the vertical leg into the wall base. Use the handle on the side to tighten and secure the vertical leg.



3. Place the horizontal leg on top of the vertical leg repeat the tightening process with the handle on the horizontal leg.



4. Attach the table base to the table (customer provided) using the screws (not provided) appropriate for the substrate. Place the table on top of the horizontal leg and repeat the tightening process with the handle.

To adjust the tilting Mod leg, pull the table toward you and rotate right or left until you reach the desired angle. Make sure the leg clicks in place.



3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
DOC #: 710-00202 · Rev C · 05/22/23