

Redwood™ Table Leg

Part#: TL5000, TS5020 & TS5003

INSTALLATION INSTRUCTIONS


PARTS/TOOLS NEEDED:

				
Table Base	Floor Base	Table Leg	#10 Phillips Oval Head Screws (not provided)	Power Drill (Not Provided)

INSTALLATION CONSIDERATIONS

- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not sit on or lean on table, intended for use as a table only.

- 1.** Mount the floor base into solid floor structure (wood, fiberglass, etc.) using #10 phillips oval head screws.




- 2.** Mount the table base onto table top (customer provided) using #10 phillips oval head screws. Make sure the weight of the table top is evenly supported over the table leg.

The top of the table leg has a positive lock so the table will click in place.



- 3.** To secure, slot the T piece into the base and rotate clockwise. Make sure the T-bolt is extended all the way down. To loosen, turn the leg counter-clockwise.



3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
Rev A • 01/10/23