

VersiControl RGB Control Pad

INSTALLATION INSTRUCTIONS

Part#: 21055 or 21057




PARTS / TOOLS NEEDED:

				
VersiControl RGB 4-Zone or 2-Zone Smart Pad	RGB Lighting (Varies)	Mounting Screws x 2	2" Hole Saw Bit (not provided)	Power Drill


Safety Instructions

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not install any luminaire assembly closer than 6" from any combustible materials.
- Positive (+) inputs require a fuse if the attached wire leads are not rated to handle the max current.

1. INSTALL 21055 CONTROL PAD: Determine the installation location of your control pad. Note the control module comes with a 7" long cord so the control pad will need to be located near the module. Drill a 2" hole and insert the control pad. Install the mounting bracket using the two M2x8mm stainless steel #10 torx head screws provided. Do not fully torque screws until both have been partially installed.




INSTALL 21057 CONTROL PAD: Determine the installation location of your control pad. Note the control module comes with a 7" long cord so the control pad will need to be located near the module. Drill a 2.125" hole and insert the control pad. Note, this version will only work with a 1/8" thick mounting surface.




3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
DOC #: 710-00026 · Rev E · 08/10/21

2. CONNECT CONTROL PAD: Insert the connector on the control pad into the connector on the module.



*Mating connector Deutsch DTM06-6S



3. OPERATION: Below is the keypad overview, for more detailed operational instructions, review your owners manual or visit <http://www.itc-marine.com/product-category/lighting/versicolor-rgb/>

RGB Indicator LED

- If adjusting colors, this will indicate the current color selected
- If Quick White button is pressed LED will turn white and flash

Brightness Adjust Mode

- Enables the ability to adjust the brightness of light output

Left & Right Buttons

- **Color Mode:** Cycle through RGB colors
- **Dim Mode:** Increase or decrease brightness of light
- **Fade Mode:** Increase or decrease fade speed

Zone 3 & 4

- If utilizing the two-zone control pad, these buttons will be blank

Main Power

- Turns system on/off. When powered back on system returns to previous state

Color Select Mode

- Enables RGB color selection within currently selected mode

Zone Select Buttons

- Enables selection of zones 1 - 4 to initiate a color or mode change within that zone

Effects Mode

- Enables seven color face within the active zones

Quick White Button

- One press turns all zones white
- Press again to return to previous state



Note: To reset the Bluetooth passcode and clear lock zones, press and release both arrow keys at the same time.



3030 Corporate Grove Dr.
Hudsonville, MI 49426
Phone: 616.396.1355
itc-us.com

For warranty information please visit www.itc-us.com/warranty-return-policy
DOC #: 710-00026 · Rev E · 08/10/21