



# Vogue™ Linear Light

Part#: RLLL-KKX-FF

## INSTALLATION INSTRUCTIONS

### PARTS/TOOLS NEEDED:

	
Vogue Linear Light	Router (Not Provided)


### IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- It is recommended that fuse protection be added to the positive (+) input.


1. Determine the installation location for your light router out the correct size of hole. This will be .875" wide by the length of your light. Be sure to check the internal measurement and excluding the bezel for this installation.



2. Push the light into the routed out space. By putting the light into the routed out space you will engage the mounting clips and they will hold the light in place



3. Wire the light following the wiring diagram below.



3030 Corporate Grove Dr.  
Hudsonville, MI 49426  
Phone: 616.396.1355  
[itc-us.com](http://itc-us.com)

For warranty information please visit [www.itc-us.com/warranty-return-policy](http://www.itc-us.com/warranty-return-policy)  
DOC #: 710-00178 · Rev A · 11/09/2022